

TECHNICAL DATA SHEET



Isolator Cleaning Tool by Texwipe



Mops



Covers



Heads & Handles

Description

Specially engineered to work with isolators and other small areas, this easy-to-manuever tool offers lightweight, one-hand operation. With a low-profile, swivel head, the Isolator Cleaning Tool gets into hard-to-reach places.

Engineered for quick cover changes during operation, the padded head allows for a consistent mop across different surfaces without losing cleaning power. The rounded edges clean the isolator corners and prevent scratches or damages to surfaces. The low-profile, swivel head

Texwipe's Isolator Cleaning Tool/Mini AlphaMop™ Systems feature a 7" x 4" (10 cm x 18 cm) thermoplastic mop head, pads and fasteners. Choose from your choice of handle options: TX7101 offers 2 handles at 12" (30.4 cm) and 18" (45 cm) fixed lengths each, and TX7104 offers a telescoping handle reaching from 29" - 53" (73 cm - 134 cm). Autoclave safe.

Features & Benefits

- Rapid-change system allows user to replace covers / pads frequently, adhering to strict cleaning protocol
- Conforms to surfaces with its polyester pad
- Gets into hard-to-reach areas with its low profile, swivel head
- Texwipe's 100% polyester covers provide the cleanest substrates available for cleaning isolators
- Offers one-hand operation with lightweight handles

Applications

- Isolators
- Small, hard-to-reach areas
- Glove boxes, biosafety cabinets, laminar flow hoods
- Workbenches
- **Industries:** Compounding Pharmacy, Pharmaceuticals, Biologics, Medical Device, Microelectronics, Semiconductor

Products

Number	Description	Packaging
MOP HARDWARE		
TX7101	Isolator Cleaning Tool Kit (1) 7" x 4" (10 cm x 18 cm) thermoplastic mop head, (1) 12" (30.4 cm) fiberglass handle, (1) 18" (45 cm) fiberglass handle, 1 polyester pad, (2) fastening pins, (6) sample covers of TX7114M and (5) sample covers of STX7114	1 per case
TX7104	Isolator Cleaning Tool Kit (1) 7" x 4" (10 cm x 18 cm) thermoplastic mop head, (1) 29"-53" (73 cm - 134 cm) telescoping fiberglass handle, 1 polyester pad, (2) fastening pins, (6) sample covers of TX7114M and (5) sample covers of STX7114	1 per case
REPLACEMENT HEAD		
TX7105	Isolator Cleaning Tool Replacement Head (1) 7" x 4" (10 cm x 18 cm) thermoplastic mop head, (1) pad	1 per case
REPLACEMENT HANDLES		
TX7120	12" Isolator Cleaning Tool Replacement Handle 12" (30.4 cm), white fiberglass, autoclave safe	1 per case
TX7121	18" Isolator Cleaning Tool Replacement Handle 18" (45 cm), white fiberglass, autoclave safe	1 per case
TX7122	29" - 53" Isolator Cleaning Tool Extension Handle 29" to 53" (73 cm - 134 cm) telescoping, white fiberglass, autoclave safe	1 per case

TECHNICAL DATA SHEET



Description

Replacement covers for the Isolator Cleaning Tool/Mini AlphaMop are available in a choice of 100% polyester and microdenier. Each package includes covers and pads for an optimal fit and double-bagged for easy introduction into clean environments. Sterile options available.

Polyester

Made from cleanroom-laundered, knitted-polyester and available in sterile where indicated. Made from Texwipe's AlphaWipe 100% polyester, these covers provide the cleanest mop cover available for walls, floors and isolator ceilings. Ideal for cleaning processes requiring low particle, extractable and ionic contamination.

- 100% polyester material provides a clean mop cover ideal for walls, floors and isolator ceilings.
- Ideal for processes requiring low particle, extractable and ionic contamination.

Microdenier

Made from 100% polyester microdenier fabric and available in a sterile option. This fabric provides enhanced particle lifting, streak-free cleaning, plus enhanced sorption for working with solutions.

- Enhanced absorbency and quick-wicking performance
- Increased lifting and capturing of particles as small as microbes
- Compatible with all disinfectants, including quats such as Texwipe's TexQ.
- Streak-free cleaning

Sterile Products Available:

- » Gamma irradiated to a Sterility Assurance Level of 10^{-6} in accordance with AAMI TIR33: 2005
- » Lot code and expiration date clearly marked on each package
- » Certificates of Irradiation and Compliance attached to each case confirm irradiation dose met specifications
- » Pre-sterilization eliminates repackaging, documentation and validation of autoclaving

Isolator Cleaning Tool by Texwipe



Mops



Covers



Heads & Handles

Applications

- Cleaning walls, ceilings and floors in critically clean or cleanroom environments
- Applying and removing solutions including disinfectants
- **Industries:** Microelectronics, Semiconductor, Pharmaceuticals, Biologics, Medical Device, Compounding Pharmacy

Products

Number	Description	Packaging
Polyester		
TX7114	Isolator Cleaning Tool Polyester Covers and polyester pads	Covers: 25 covers per bag, 6 bags per case Pads: 6 replacement pads per case
STX7114	Sterile Isolator Cleaning Tool Polyester Covers and polyester pads	5 covers and 1 pad per bag; 25 bags per case
Microdenier		
TX7114M	Isolator Cleaning Tool Microdenier Covers and polyester pads	Covers: 25 covers per bag, 6 bags per case Pads: 6 replacement pads per case
STX7114M	Sterile Isolator Cleaning Tool Microdenier Covers and polyester pads	5 covers and 1 pad per bag; 25 bags per case

T E C H N I C A L D A T A S H E E T

Products

Number	Description
--------	-------------

MOP HARDWARE

TX7101	Isolator Cleaning Tool Kit with 2 handles
--------	---

TX7104	Isolator Cleaning Tool Kit with 1 telescoping handle
--------	--

REPLACEMENT PARTS

Replacement Head

TX7105	Isolator Cleaning Tool Replacement Head
--------	---

Replacement Handles

TX7120	12" Isolator Cleaning Tool Replacement Handle
--------	---

TX7121	18" Isolator Cleaning Tool Replacement Handle
--------	---

TX7122	29" - 53" Isolator Cleaning Tool Extension Handle
--------	---

COVER REFILLS

Polyester

TX7114	Isolator Cleaning Tool Polyester Cover and polyester pads
--------	---

STX7114	Sterile Isolator Cleaning Tool Polyester Cover and polyester pads
---------	---

Microdenier

TX7114M	Isolator Cleaning Tool Microdenier Covers and polyester pads
---------	--

STX7114M	Sterile Isolator Cleaning Tool Microdenier Covers and polyester pads
----------	--

Texwipe Regulatory Certificates

Texwipe is the only wiper company to be registered: ISO 9001 • ISO 13485 • ISO 14001